

# Assembly and mounting options

## Finials

For topping columns, a wide range of finials are available in either cast iron or aluminium and are secured to the shaft by a grub screw.

## Column Height Extensions

Steel column extensions are added to existing columns if additional arms are required.

## Recess

## Spacer Collars

Spacer collars allow a gap either between finger arms or full gaps that may accommodate future additional arms.

## Finger Arms

Finger arms are manufactured from cast aluminium.



## Steel Shaft (included in column price)

Shafts are made of mild steel with a 76mm diameter, height as required.


## Mounting options

## Column


Columns are available in cast iron, cast aluminium, ductile iron or mild steel.



With steel extended root, for setting directly into a concrete foundation.



Submerged base plate for bolting to concrete block below ground level.



Base extension piece; to allow base plated columns to be secured below ground. Base extension may also be root anchored.